


ABLOY® STRIKER PLATES

Striker plate must always be used with a lock!


Striker plate is not always automatically included in the lock case delivery.

ABLOY® ELECTROMECHANICAL ACCESSORIES


EL580, EL582
EL590



EL554, EL555




EL512




ABLOY® ELECTROMECHANICAL ACCESSORIES

EL480, EL482
EL490
EL412
EL512 in metal doors




EL648, EL650




ABLOY® ELECTROMECHANICAL ACCESSORIES

Striker plates for Europrofile DIN range locks


EA321




EA322



EA323




EA324




ABLOY® ELECTROMECHANICAL ACCESSORIES

Striker plates for Europrofile DIN range locks


EA325




EA326




EA327



EA328




EA329




ABLOY® ELECTROMECHANICAL ACCESSORIES

Striker plates for Europrofile DIN range locks

EA330



EA331



EA332 (left and right)

